

Mounting instruction

pewag ladder chains without camlocks (E-S chains)



Mounting instruction

1



Hang the chain into the tire thread by means of the enclosed mounting cable.

2



Drive forward one full turn of the wheel, check successful mounting of the chain and remove mounting cable.

3



Close chain ends, beginning with the inside hook (see magnifier).

4




Then tighten the outside chain and close it by means of the tension lever.

Please read the vehicle manufacturer's manual and enclosed precaution instructions carefully.

pewag Schneeketten GmbH

A-9371 Brückl, Kettenwerk 1, Phone: +43 505011-0, Fax: +43 505011-100

schneeketten@pewag.com, www.pewag.com



MA/00554 9 1006350112913

